

Honeywell Barcode Scanner Configuration Barcodes

After each code you have to wait for a confirmation beep. Depending on this model the confirmation beep sound differs, but most scanners use at least a two-tone beep to indicate a successful configuration scan. (Regular product code scans are confirmed with a single beep.)

1. Reset to factory settings



* *Voyager 1202g only*: as the handheld and cradle have to synchronize again, return the handheld to the scanner now. Continue with next step after confirmation beep.

2. Switch to USB HID mode



3. Set beep level to *low*



4. Remove suffixes from scanned barcodes

