

Honeywell Barcode Scanner Configuration Barcodes

After each code you have to wait for a confirmation beep. Depending on this model the confirmation beep sound differs, but most scanners use at least a twotone beep to indicate a successful configuration scan. (Regular product code scans are confirmed with a single beep.)

1. Reset to factory settings



DEFAULT.

Activate Custom Defaults

* *Voyager 1202g only*: as the handheld and cradle have to synchronize again, return the handheld to the scanner now. Continue with next step after confirmation beep.

2. USB HID barcode scanner



PAP131.

USB HID Bar Code Scanner

3. Set beep level to low



BEPLVL1.

Low

4. Add suffixes from scanned barcodes



SUFBK2.

Add Suffix

5. Convert UPCA to EAN13



UPAENA0.

UPC-A Converted to EAN-13